


# INSTALLATION AND OWNER'S MANUAL

Air to Water Heat Pump System Tri-Thermal Monobloc



# CONTENTS

1 SAFETY PRECAUTIONS	01
2 BEFORE INSTALLATION	05
3 IMPORTANT INFORMATION FOR THE REFRIGERANT	05
4 INSTALLATION SITE	05
5 INSTALLATION PRECAUTIONS	08
6 OVERVIEW OF THE UNIT	11
7 TEST RUN AND FINAL CHECKS	26
8 MAINTENANCE AND SERVICE	26
9 TURN OVER TO CUSTOMER	27
10 OPERATION AND PERFORMANCE	
11 ERROR CODES	
12 TECHNICAL SPECIFICATIONS	34
13 INFORMATION SERVICING	

# **1 SAFETY PRECAUTIONS**

The precautions listed here are divided into the following types. They are quite important, so be sure to follow them carefully. Read these instructions carefully before installation. Keep this manual well for future preference.

Meanings of DANGER, WARNING, CAUTION and NOTE symbols.

### $({ m i})$ information -

- · Read these instructions carefully before installation. Keep this manual handy for future peference.
- Improper installation of equipment or accessories may result in electric shock, short-circuit, leakage, fire or other damage to the equipment.
- Be sure to only use accessories made by the supplier, which are specifically designed for the equipment and ensure that the installation is completed by professionals.
- All the activities described in this manual must be carried out by licensed technicians. Be sure to wear adequate personal protection
  equipment such as gloves and safety glasses while installing the unit or carrying out maintenance activities.
- · Contact your dealer for any further assistance.

# 

Indicates an imminently hazardous situation which if not avoided, will result in death or serious injury.

# 

Indicates a potentially hazardous situation which if not avoided, could result in death or serious injury.

# 

Indicates a potentially hazardous situation which if not avoided, may result in minor or moderate injury. It is also used to alert against unsafe practices.

# 

Indicates situations that could only result in accidental equipment or property damage.

- Improper installation of equipment or accessories may result in electric shock, short-circuit, leakage, fire or other damage to the
  equipment. Be sure to only use accessories made by the supplier, which are specifically designed for the equipment and make sure
  to get installation done by a certified person.
- All the activities described in this manual must be carried out by a licensed technician. Be sure to wear adequate personal protection
  equipment such as gloves and safety glasses while installing the unit or carrying out maintenance activities.



Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.

### **Special requirements for R32**

#### 

- · Do not have refrigerant leakage and open flame.
- Be aware that the R32 refrigerant does NOT contain an odour.

#### 

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (example:open flames, an operating gas appliance) and have a room size as specified below.

#### 

Make sure installation, servicing, maintenance and repair comply with instruction and with applicable legislation (for example national gas regulation) and are executed only by authorized persons.

- · Pipework should be protected from physical damage.
- · Installation of pipework shall be kept to a minimum length.

### Explanation of symbols displayed on the monobloc

	WARNING	This symbol shows that this appliance used a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire.
	CAUTION	This symbol shows that the operation manual should be read carefully.
	CAUTION	This symbol shows that service personnel should handle this equipment with reference to the installation manual.
	CAUTION	This symbol shows that a service personnel should be handling this equipment with reference to the installation manual.
Ĩ	CAUTION	This symbol shows that information is available such as the operating manual or installation manual.

# 

- · Before touching electric terminal parts, turn off power switch.
- When service panels are removed, live parts can be easily touched by accident.
- · Never leave the unit unattended during installation or servicing when the service panel is removed.
- Do not touch water pipes during or immediately after operation as the pipes may be hot and could burn your hands. To avoid injury, wait
  until the pipes cool down to odinary temperature or be sure to wear protective gloves.
- Do not touch any switch with wet hands. Touching the switch with wet hands can cause electrical shock.
- · Before touching electrical parts, turn off all applicable power to the unit.

- Tear apart and throw away plastic packaging bags so that children will not play with them. Children playing with plastic bags face danger of death by suffocation.
- · Safely dispose of packing materials such as nails, other metal and wood parts that could cause injuries.
- Ask your dealer or qualified personnel to perform installation work in accordance with this manual. Do not install the unit by yourself. Improper installation could result in water leakage, electric shocks or fire.
- Be sure to use only specified accessories and parts for installation work. Failure to use specified parts may result in water leakage, electric shocks, fire, or the unit falling from its mount.
- Install the unit on a foundation that can withstand its weight. Insufficient physical strength may cause the equipment to fall and
  possible cause injury.
- Perform specified installation work with full consideration of strong wind, hurricanes, or earthquakes. Improper installation work may
  result in accidents due to equipment falling.
- Make certain that all electrical work is carried out by qualified personnel according to the local laws and regulations and this manual using a separate circuit. Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or fire.
- Be sure to install a ground fault circuit interrupter according to local laws and regulations. Failure to install a ground fault circuit interrupter may cause electric shocks and fire.
- Make sure all wirings are secure. Use the specified wires and ensure that terminal connections or wires are protected from water and other adverse external forces. Incomplete connection or affixing may cause a fire.
- When wiring the power supply, form the wires so that the front panel can be securely fastened. If the front panel is not in place there could be overheating of the terminals, electric shocks or fire.
- · After completing the installation work, check to make sure that there is no refrigerant leakage.
- Never directly touch any leaking refrigerant as it could cause severe frostbite. Do not touch the refrigerant pipes during or immediately after operation as the refrigerant pipes may be hot or cold, depending on the condition of the refrigerant flowing through the refrigerant piping, compressor and other refrigerant cycle parts. Burns or frostbite are possible if you touch the refrigerant pipes. To avoid injury, give the pipes time to return to normal temperature. If you must touch them, be sure to wear protective gloves.
- Do not touch the internal parts (pump, backup heater, etc.) during or immediately after operation. Touching the internal parts will
  cause burns. To avoid injury, give the internal parts time to return to normal temperature. If you must touch them, be sure to wear
  protective gloves.

- Ground the unit.
- Grounding resistance should be according to local laws and regulations.
- Do not connect the ground wire to gas or water pipes, lightning conductors or telephone ground wires.
- Incomplete grounding may cause electric shocks.
  - Gas pipes: Fire or an explosion may occur if the gas leaks.
  - Water pipes: Hard vinyl tubes are not effective grounds.
  - Lightning conductors or telephone ground wires: Electrical threshold may rise abnormally if struck by a lightning bolt
- Install the power wire at least 3 feet (1 meter) away from televisions or radios to prevent interference or noise. (Depending on the radio waves, a distance of 3 feet (1 meter) may not be sufficient to eliminate the noise.)
- Do not wash the unit. This may cause electric shocks or fire. The appliance must be installed in accordance with national wiring
  regulations. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in
  order to avoid a hazard.
- Do not install the unit in the following places:
  - Where there is mist of mineral oil, oil spray or vapors. Plastic parts may deteriorate, and make them become loose or water leakage.
- Where corrosive gases (such as sulphurous acid gas) are produced. Where corrosion of copper pipes or soldered parts may cause refrigerant to leak.
- Where there is machinery which emits electromagnetic waves. Electromagnetic waves can disturb the control system and cause equipment malfunction.

- Where flammable gases may leak, where carbon fiber or ignitable dust is suspended in the air or where volatile flammables such as paint thinner or gasoline are handled. These types of gases might cause a fire.

- Where the air contains high levels of salt such as near the ocean.
- Where voltage fluctuates a lot, such as in factories.
- In vehicles or vessels.
- Where acidic or alkaline vapors are present.
- This appliance can be used by children 8 years old and above and persons with reduced physical, sensory or mental capabilities or lack
  of experience and knowledge if they are supervised or given instruction on using the unit in a safe manner and understand the hazards
  involved. Children should not play with the unit. Cleaning and user maintenance should not be done by children without supervision.
- · Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person.
- DISPOSAL: Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is
  necessary. Do not dispose of electrical appliances as municipal waste, use separate collection facilities. Contact your local government
  for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous
  substance can leak into the groundwater and get into the food chain, damaging your health and well-being.
- The wiring must be performed by certified person technicians in accordance with national wiring regulation and this circuit diagram. An
  all-pole disconnection device which has at least 3mm separation distance in all pole and a residual current device (RCD) with the rating
  not exceeding 30mA shall be incorporated in the fixed wiring according to the national rule.
- Confirm the safety of the installation area ( walls, floors, etc. ) without hidden dangers such as water, electricity, and gas before wiring/pipes.
- Before installation, check whether the user's power supply meets the electrical installation requirements of unit (including reliable grounding, leakage, and wire diameter electrical load, etc.). If the electrical installation requirements of the product are not met, the installation of the product is prohibited until the product is rectified.
- Product installation should be fixed firmly. Take reinforcement measures when necessary.

# 

- About Fluorinated Gases
  - This heat pump unit contains fluorinated gases. For specific information on the type of gas and the amount, please refer to the relevant label on the unit itself. Compliance with national gas regulations shall be observed.
  - Installation, service, maintenance and repair of this unit must be performed by a certified technician.
  - Product uninstallation and recycling must be performed by a certified technician.

- If the system has a leak-detection system installed, it must be checked for leaks at least every 12 months. When the unit is checked for leaks, proper record-keeping of all checks is strongly recommended.

# **2 BEFORE INSTALLATION**

### **Before installation**

Be sure to confirm the model name and the serial number of the unit.

# CAUTION -

Frequency of Refrigerant Leakage Checks

- For unit that contains fluorinated greenhouse gases in quantities of 5 tonnes of  $CO_2$  equivalent or more, but of less than 50 tonnes of  $CO_2$  equivalent, at least every 12 months, or where a leakage detection system is installed, at least every 24 months.

- For unit that contains fluorinated greenhouse gases in quantities of 50 tonnes of CO<sub>2</sub> equivalent or more, but of less than 500 tonnes of CO<sub>2</sub> equivalent at least every six months, or where a leakage detection system is installed, at least every 12 months.

- For unit that contains fluorinated greenhouse gases in quantities of 500 tonnes of  $CO_2$  equivalent or more, at least every three months, or where a leakage detection system is installed, at least every six months.

- This heat pump unit is a hermetically sealed equipment that contains fluorinated greenhouse gases.

- Only certificated person is allowed to do installation, operation and maintenance.

# **3 IMPORTANT INFORMATION FOR THE REFRIGERANT**

This product has the fluorinated gas, it is forbidden to release to air. Refrigerant type: R32; Volume of GWP: 675. GWP=Global Warming Potential

Model	Factory charged refrigerant volume in the unit				
Widdei	Refrigerant/kg	Tonnes CO <sub>2</sub> equivalent			
8kW	1.4	0.95			
10kW	1.4	0.95			
12kW	1.74	1.18			
14kW	1.74	1.18			
16kW	1.74	1.18			

# CAUTION -

- · Frequency of Refrigerant Leakage Checks
  - Equipment that contains less than 3 kg of fluorinated greenhouse gases or hermetically sealed equipment, which is labelled accordingly and contains less than 6 kg of fluorinated greenhouse gases shall not be subject to leak checks.
  - For unit that contains fluorinated greenhouse gases in quantities of 5 tonnes of CO<sub>2</sub> equivalent or more,but of less than 50 tonnes of CO<sub>2</sub> equivalent,at least every 12 months, or where a leakage detection system is installed, at least every 24 months.
  - Only certificated person is allowed to do installation, operation and maintenance.

# **4 INSTALLATION SITE**

- There is flammable refrigerant in the unit and it should be installed in a well-ventilated site. If the unit is installed inside, an additional refrigerant detection device and ventilation equipment must be added in accordance with the standard EN378. Be sure to adopt adequate measures to prevent the unit from being used as a shelter by small animals.
- Small animals making contact with electrical parts can cause malfunction, smoke or fire. Please instruct the customer to keep the area around the unit clean.
- The equipment is not intended for use in a potentially explosive atmosphere.

Select an installation site where the following conditions are satisfied and one that meets with your customer's approval.

- Places that are well-ventilated.

- Places where the unit does not disturb next-door neighbors.
- Safe places which can bear the unit's weight and vibration and where the unit can be installed at an even level.
- Places where there is no possibility of flammable gas or product leak.
- The equipment is not intended for use in a potentially explosive atmosphere.
- Places where servicing space can be well ensured.
- Places where the units' piping and wiring lengths come within the allowable ranges.
- Places where water leaking from the unit cannot cause damage to the location (e.g. in case of a blocked draining pipe).
- Places where rain can be avoided as much as possible.

- Do not install the unit in places often used as a work space. In case of construction work (e.g. grinding etc.) where a lot of dust is created, the unit must be covered.

- Do not place any object or equipment on top of the unit (top plate).
- Do not climb, sit or stand on top of the unit.

- Be sure that sufficient precautions are taken in case of refrigerant leakage according to relevant local laws and regulations.- Don't install the unit near the sea or where there is corrosion gas.


When installing the unit in a place exposed to strong wind, pay special attention to the following.

Strong winds of 5 m/sec or more blowing against the unit's air outlet causes a short circuit (suction of discharge air), and this may have the following consequences:

- Deterioration of the operational capacity.
- Frequent frost acceleration in heating operation.
- Disruption of operation due to rise of high pressure.
- Motor burnout.
- When a strong wind blows continuously on the front of the unit, the fan can start rotating very fast until it breaks.

### 4.1 Installation Site

In normal condition, refer to the figures below for installation of the unit:



- Make sure there is enough space to do the installation. Set the outlet side at a right angle to the direction of the wind.
- · Prepare a water drainage channel around the foundation, to drain waste water from around the unit.
- If water does not easily drain from the unit, mount the unit on a foundation of concrete blocks, etc. (the height of the foundation should be about 100 mm.
- When installing the unit in a place frequently exposed to snow, pay special attention to elevate the foundation as high as possible.
- If you install the unit on a building frame, please install a waterproof plate (field supply) (about 100mm, on the underside of the unit) in order to avoid drain water dripping. (See the picture in the right).

### 4.1.1 Selecting a location in cold climates

# 

When operating the unit in cold climates, be sure to follow the instructions described below.

- To prevent exposure to wind, install the unit with its suction side facing the wall.
- Never install the unit at a site where the suction side may be exposed directly to wind.
- To prevent exposure to wind, install a baffle plate on the air discharge side of the unit.
- In heavy snowfall areas, it is very important to select an installation site where the snow will not affect the unit. If lateral snowfall is possible, make sure that the heat exchanger coil is not affected by the snow (if necessary construct a lateral canopy).

### 4.1.2 Prevent sunshine

As the outdoor temperature is measured via the monobloc air thermistor, make sure to install the monobloc in the shade or a canopy should be constructed to avoid direct sunlight, so that it is not influenced by the sun's heat, otherwise protection may be possible to the unit.

# 

Uncovered scene, anti-snow shed must be installed:

(1)To prevent rain and snow from hitting the heat exchanger, resulting in poor heating capacity of the unit, after long time accumulation, the heat exchanger freezes;

(2)To prevent the monobloc air thermistor from being exposed to the sun, resulting in failure to boot;


(3)To prevent freezing rain.


# **5 INSTALLATION PRECAUTIONS**

### 5.1 Installation precautions

### 5.1.1 Dimensions









#### 5.1.2 Installation requirements

- Check the strength and level of the installation ground so that the unit may not cause any vibrations or noise during the operation.
- In accordance with the foundation drawing in the figure, fix the unit securely by foundation bolts. (Prepare six sets each of Φ10 Expansion bolts, nuts and washers which are readily available in the market.)
- Screw in the foundation bolts until their length is 20mm from the foundation surface.





### 5.1.3 Drainage kit installation

ODU drainage kit installation


Fasten the drain kit(accessories) to the hole on the bottom tray as shown in the picture; If a drain pipe is required, connect the drain pipe to the drain kit as shown in the picture, and guide the condensed water and defrosting water to a suitable place.

#### Notice:

1. If necessary, please contact the after-sales service to purchase the ODU drain pipe.

2.Heat&cool unit need to drain the condensed water from ODU.Only cooling units needn't.

3.In wet and cold areas in winter, the drained water is easy to freeze, which may damage the fan. Therefore, it is recommended not to install a drain kit, otherwise it is not good for drainage and protection of the machine.



# 

It's necessary to install an electrical heating belt if water can't drain out in cold weather even the big drain hole has opened. It is suggested to site the unit with the base electric heater.

#### 5.14 Filling water

- · Connect the water supply to the filling valve and open the valve.
- Make sure all the automatic air purge valve are opened (1.5-2 turns).
- · Remove air in the circuit as much as possible using the automatic air purge valve.

Do not fasten the black plastic cover on the automatic air purge valve at the topside of the unit when the system is running.Open the automatic air purge valve, turn it counterclockwise for 1.5-2 turns to release air from the system.



# 

During filling, it might not be possible to remove all air in the system. Remaining air will be removed through the automatic air purge valve during the first operating hours of the system. Topping up the water afterwards might be required.

- · At all times water pressure should remain above 0.3 bar to avoid air entering the circuit.
- The unit might drain-off too much water through the pressure relief valve.
- Water quality should be complied with EN 98/83 EC Directives.


### 5.15 BEFORE INSTALLATION

- Before installation
- Be sure to confirm the model name and the serial number of the unit.
- Handling

Due to relatively large dimensions and heavy weight, the unit should only be handled using lifting tools with slings. The slings can be fitted into foreseen sleeves at the base frame that are made specifically for this purpose.


# 


- To avoid injury, do not touch the air inlet or aluminum fins of the unit.
- Do not use the grips in the fan grills to avoid damage.
- The unit is top heavy! Prevent the unit from falling due to improper inclination during handling.



Model	А	В	С
8/10/12/14/16kW	290	515	230

The position of barycenter for different units can be seen in the picture below.






8/10/12/14/16 kW (unit:mm)

### 5.2 Servicing space requirements

### 5.2.1 In case of stacked installation

1) In case obstacles exist in front of the outlet side.


2) In case obstacles exist in front of the air inlet.



Unit	A(mm)
8~16kW	≥2000

### 5.2.2 In case of multiple-row installation (for roof top use, etc.)

In case of installing multiple units in lateral connection per row.



# **6 OVERVIEW OF THE UNIT**

## 6.1 Field wiring

# 

A main switch or other means of disconnection, having a contact separation in all poles, must be incorporated in the fixed wiring in accordance with relevant local laws and regulations. Switch off the power supply before making any connections. Use only copper wires. Never squeeze bundled cables and make sure they do not come in contact with the piping and sharp edges. Make sure no external pressure is applied to the terminal connections. All field wirings and components must be installed by a licensed electrician and must comply with relevant local laws and regulations.

The field wiring must be carried out in accordance with the wiring diagram supplied with the unit and the instructions given below.

Be sure to use a dedicated power supply. Never use a power supply shared by another appliance.

Be sure to establish a ground. Do not ground the unit to a utility pipe, surge protector, or telephone ground. Incomplete grounding may cause electrical shock.

Be sure to install a ground fault circuit interrupter (30 mA). Failure to do it may cause electrical shock.

Be sure to install the required fuses or circuit breakers.

### 6.1.1 Precautions on electrical wiring work


- · Fix cables so that cables do not make contact with the pipes (especially on the high pressure side).
- Secure the electrical wiring with cable ties as shown in figure so that it does not come in contact with the piping, particularly on the high-pressure side.
- · Make sure no external pressure is applied to the terminal connectors.
- When installing the ground fault circuit interrupter make sure that it is compatible with the inverter (resistant to high frequency electrical noise) to avoid unnecessary opening of the ground fault circuit interrupter.

#### 

The ground fault circuit interrupter must be a high-speed type breaker of 30 mA (<0.1 s).

This unit is equipped with an inverter. Installing a phase advancing capacitor not only will reduce the power factor improvement effect, but
also may cause abnormal heating of the capacitor due to high-frequency waves. Never install a phase advancing capacitor as it could lead to
an accident.

### 6.1.2 Wiring overview



Code	Assembly unit	Code	Assembly unit
1	Monobloc	15	Zone 2 pump(P_M)
2	Wire controller	16	Zone 2 floor heating water inlet temperature sensor(Tw_2)
3	Stop valve	17	Zone 3 room thermostat
4	Check valve	18	Zone 3 indoor temperature sensor(Tr_3)
5	Three-way valve 1(SV1)	19	Zone 3 mixing valve
6	Buffer tank	20	Zone 3 pump(P_T)
7	Buffer tank electric heater(IBH1)	21	Zone 3 floor heating water inlet temperature sensor
8	Zone 1 pump(P_O)	22	Domestic hot water tank
9	Three-way valve 2(SV2)	23	Water tank electric heating(TBH)
10	Zone 1 room thermostat	24	Domestic hot water pump(P_R)
11	Zone 1 indoor temperature sensor(Tr_1)	25	Solar energy water pump(P_S)
12	Zone 2 room thermostat	26	Solar panels
13	Zone 2 indoor temperature sensor (Tr_2)	27	Power supply
14	Zone 2 mixing valve	28	Contactor

# 

a. When using the mixing valve in Zone 3, the terminals connected are position 2(MV2), 14(4ON), 10(N).

b. Zone 2: Setting the mixing valve (to the hot water direction 8(3ON), to the cold water direction 1(MV1); Zone 3: Setting the mixing valve, 14(4ON) is for the hot water direction, 2(MV2) is to the cold water direction.

c. Code 7-32 are field supply.

	Wiring requirements						
ltem	Description	Current	Required number of conductors	Maximum running current			
1	Solar energy kit signal cable	AC	2	200mA			
2	User interface cable	AC	5	200mA			
3	Room thermostat cable	AC	2	200mA(1)			
4	Solar pump control cable	AC	2	200mA(1)			
5	Outside circulation pump control cable	AC	2	200mA(1)			
6	DHW pump control cable	AC	2	200mA(1)			
7	SV2: Three-way valve control cable	AC	3	200mA(1)			
8	SV1: Three-way valve control cable	AC	3	200mA(1)			
9	Booster heater control cable	AC	2	200mA(1)			

(1) Minimum cable section AWG18 (0.75mm<sup>2</sup>).

If the current of the load is large, an AC contactor is needed.

# 

Please use H07RN-F for the power wire, all the cables are connected to high voltage except for thermistor cable and cable for user interface.

Equipment must be grounded.

· All high-voltage external load, if it is metal or a grounded port, must be grounded.

• All external load current is needed less than 0.2A, if the single load current is more than 0.2A, the load must be controlled through AC contactor.

- "AHS1" "AHS2", "H" "C" etc, wiring terminal ports provide only the switch signal.
- · Please refer to image of 6.2.7 to get the ports position in the unit.
- Plate heat exchanger E-Heating tape and Expanssion vessel E-Heating tape share a control port.

#### Field wiring guidelines


• Most field wiring on the unit is to be made on the terminal block inside the switch box. To gain access to the terminal block, remove the switch box service panel.

# 

Switch off all power including the unit power supply and backup heater and domestic hot water tank power supply (if applicable) before removing the switch box service panel.

- Fix all cables using cable ties.
- A dedicated power circuit is required for the backup heater.
- · Installations equipped with a domestic hot water tank (field supply) require a dedicated power circuit for the booster heater.
- · Lay out the electrical wiring so that the front cover will not rise up when doing wiring work and attach the front cover securely.
- · Follow the electric wiring diagram for electrical wiring works (the electric wiring diagrams are located on the service panel.
- . Install the wires and fix the cover firmly so that the cover may be fit in properly.

### 6.1.3 Wiring overview of cascade system



### · Domestic water heating

Only master unit (1) can run in DHW mode.When master unit running in DHW mode, the slave unit only can run in heating mode. DHW mode and cool mode can't run at the same time.

#### Slave heating

All slave units can run in cooling or heating mode, and the runing mode and temperature setting change with the change of the master unit. There may be multiple units runing at different times due to changes in outdoor temperature and indoor required load.

### • AHS(Auxiliary heat source) Control

AHS should be connected to the corresponding port of the master unit, and only controlled by the master unit, not controlled by the slave unit.

### • TBH (Tank booster heater ) Control

TBH should be connected to the corresponding port of the master unit, and only controlled by the master unit, not controlled by the slave unit.

### Solar energy Control

Solar energy Control should be connected to the corresponding port of the master unit, and only controlled by the master unit, not controlled by the slave unit.

• Maximum 8 units can be cascaded in on system. One of them is master unit, the others are slave units; Master unit and slave units are distinguished by whether connected to wired controller while powering on. The unit with wired controller is master unit, units without wired controller are slave units; Only master unit can operate in DHW mode. While installation, please check the cascade system diagram and determine the master unit; Before powering on, remove all wired controllers of slave units.

- SV1、SV2、SV3、P\_T、P\_M、P\_O、P\_S、P\_R、MV1、MV2、SL1、SL2、AHS、TBH、M1M2、SG、EVU、C3L3、C2L2、C1L1 port are only need to be connected to corresponding ports on main board of master unit. Please refer to 6.1.1.
- The system is with auto-addressing function. After each time powering on, The unit will read its own turntable address as the cascade address, address 0 is the master unit, and addresses 1-7 are slave unit.

• If En error code occurs ,please check whether the communication line of the cascade unit is connected properly and whether the cascade setting of the wire controller is correct.

• It is suggested to use the reversed return water system in order to avoid hydraulic imbalance between each unit in a cascade system.

# 

• In the cascaded system, the system's final outlet water temperature sensor of the system (Ttots) must be connected to the master unit, and Ttots must be set on the wire controller to be valid.

- If outside circulation pump need to be connected in series in system when the head of internal water pump is not enough,outside circulation pump is suggested to be installed after the balance tank.
- Please ensure that the maximum interval between power-on times of all units does not exceed 2 minutes. If it exceeds the maximum communication detection time of the master and slave for 2 minutes, a cascade communication failure En will be reported.
- · Maximum 8 units can be cascaded in one system.
- The outlet pipe of each unit must be installed with a check valve.

### Balance tank volume requirement

NO.	model	Balance tank (L)		
1	8~10kW	≥25		
2	12~16 kW	≥40		
3 Cascade system		≥40*n		
n:The outdoor unit numbers				

### 6.1.4 Precautions on wiring of power supply

- Use a round crimp-style terminal for connection to the power supply terminal board. In case it cannot be used due to unavoidable reasons, be sure to observe the following instructions.
- Do not connect different gauge wires to the same power supply terminal. (Loose connections may cause overheating.)
- When connecting wires of the same gauge, connect them according to the figure below.



- Use the correct screwdriver to tighten the terminal screws. Small screwdrivers can damage the screw head and prevent appropriate tightening.
- · Over-tightening the terminal screws may damage the screws.
- · Attach a ground fault circuit interrupter and fuse to the power supply line.
- When wiring, make certain that prescribed wires are used, carry out complete connections, and fix the wires so that outside force cannot
  affect the terminals.

### 6.1.5 Safety device requirement

- 1. Select the wire diameters( minimum value) individually for each unit based on the table 1 and table 2, where the rated current in table 1 means MCA in table 2. In case the MCA exceeds 63A, the wire diameters should be selected according to the national wiring regulation.
- 2. Select circuit breaker that having a contact separation in all poles not less than 3 mm providing full disconnection, where MFA is used to select the current circuit breakers and residual current operation breakers:

#### Table 1

Rated current of appliance: (A)	Nominal cross-sectional area (mm <sup>2</sup> )				
	Flexible cords	Cable for fixed wiring			
≤3	0.5 and 0.75	1 and 2.5			
>3 and ≤6	0.75 and 1	1 and 2.5			
>6 and ≤10	1 and 1.5	1 and 2.5			
>10 and ≤16	1.5 and 2.5	1.5 and 4			
>16 and ≤25	2.5 and 4	2.5 and 6			
>25 and ≤32	4 and 6	4 and 10			
>32 and ≤50	6 and 10	6 and 16			
>50 and ≤63	10 and 16	10 and 25			


	Power Current						Compressor		OFM		IWPM		
System	Voltage (V)	Hz	Min. (V)	Max. (V)	MCA (A)	TOCA (A)	MFA (A)	MSC (A)	RLA (A)	kW	FLA (A)	kW	FLA (A)
8kW	220-240	50	198	264	16	19	25	-	14.5	0.17	1.4	0.087	0.66
10kW	220-240	50	198	264	17	19	25	-	15.5	0.17	1.4	0.087	0.66
8kW (3kW heater)	220-240	50	198	264	29	32	40	-	14.5	0.17	1.4	0.087	0.66
10kW (3kW heater)	220-240	50	198	264	30	32	40	-	15.5	0.17	1.4	0.087	0.66
12kW	220-240	50	198	264	26	32	40	-	24	0.17	1.4	0.087	0.66
14kW	220-240	50	198	264	28	32	40	-	26	0.17	1.4	0.087	0.66
16kW	220-240	50	198	264	30	32	40	-	28	0.17	1.4	0.087	0.66
12kW (3kW heater)	220-240	50	198	264	39	45	50	-	24	0.17	1.4	0.087	0.66
14kW (3kW heater)	220-240	50	198	264	41	45	50	-	26	0.17	1.4	0.087	0.66
16kW (3kW heater)	220-240	50	198	264	43	45	50	-	28	0.17	1.4	0.087	0.66
12kW	380-415	50	342	456	10	14	25	-	8	0.17	1.4	0.087	0.66
14kW	380-415	50	342	456	11	14	25	-	9	0.17	1.4	0.087	0.66
16kW	380-415	50	342	456	12	14	25	-	10	0.17	1.4	0.087	0.66
12kW (6kW heater)	380-415	50	342	456	19	25	32	-	8	0.17	1.4	0.087	0.66
14kW (6kW heater)	380-415	50	342	456	20	25	32	-	9	0.17	1.4	0.087	0.66
16kW (6kW heater)	380-415	50	342	456	21	25	32	-	10	0.17	1.4	0.087	0.66
12kW (9kW heater)	380-415	50	342	456	23	30	32	-	8	0.17	1.4	0.087	0.66
14kW (9kW heater)	380-415	50	342	456	24	30	32	-	9	0.17	1.4	0.087	0.66
16kW (9kW heater)	380-415	50	342	456	25	30	32	-	10	0.17	1.4	0.087	0.66


# 

MCA: Min. Circuit Amps. (A)
TOCA: Total Over-current Amps. (A)
MFA: Max. Fuse Amps. (A)
MSC: Max. Starting Amps. (A)
RLA: In nominal cooling or heating test condition, the input Amps of compressor where MAX. Hz can operate Rated Load Amps. (A)
OFM:Outdoor fan motor
IWPM:Internal Water Pump Motor
KW: Rated Motor Output
FLA: Full Load Amps. (A)

### 6.1.6 Specifications of standard wiring components


1) Equipment main Power Supply Wiring





Power Supply Wiring needs to be routed through pipelines or walls.


#### 2) Equipment Wire controller cable



The wire controller line needs to be routed through pipelines or walls.

When connecting to the power supply terminal, use the circular wiring terminal with the insulation casing. Use power cord that conforms to the specifications and connect the

power cord firmly. To prevent the cord from being pulled out by external force, make sure it is fixed securely.



## 


The ground fault circuit interrupter must be a high-speed type breaker of 30 mA (<0.1 s). Flexible cord must meet 60245IE (H07RN-F) standards.

### 3) Power line and circuit breaker selection

Unit	Maximum overcurrent protector(MOP)(A)	Wiring size(mm <sup>2</sup> )
8-10kW 1-PH	25	3×4.0
8-10kW 1-PH (3kW heater)	40	3×6.0
12-16kW 1-PH	40	3×6.0
12-16kW 1-PH (3kW heater)	50	3×10.0
12-16kW 3-PH	25	5×2.5
12-16kW 3-PH (6/9kW heater)	32	5×6.0

· Stated values are maximum values (see electrical data for exact values).


### 6.1.7 Connection for other components



Print	Connect to	Print	Connect to	Print	Connect to		
TBH	Water tenk electric besting	40FF			Internal and external comm-port		
Ν	- Water tank electric heating	40N	3-way valve 4	E			
IBH1	Deeluur electric heating	N Comm-p		IIII-port			
Ν	<ul> <li>Backup electric heating</li> </ul>	MV1		12V			
SL1	O al an annu airm al mart	MV2	Mixing valve	B1	Wire contr	oller comm-port	
SL2	<ul> <li>Solar energy signal port</li> </ul>	Ν		A1	whe contr		
10FF		P_O	Zone 1 pump	E1	1		
10N	three-way valve 1	Ν		H1			
Ν		P_M	Zone 2 pump	H2	cascad	lecomm-port	
20FF		Ν		E			
20N	three-way valve 2	P_T	Zone 3 pump		1-PH		
Ν		Ν	Zone o pump		LN		
30FF		P_S	Solar energy water pump	XT1		nowor oupplior	
3ON	three-way valve 3	Ν			3-PH	power supplier	
Ν		P_R	Domestic hot water pump	1	L1 L2 L3 N		
		Ν					


Type:Port provide the signal with 220V voltage. If the current of load is <0.2A, load can connect to the port directly.

If the current of load is 0.2A, the AC contactor is required to connected for the load.




Control signal port of indoor unit: The TBH contains terminals for solar energy , 3-way valve, pump, water tank electric heating , etc. The parts wiring is illustrated below:

### 1) For Solar energy signal port




### 2) For 3-way value


3-way value 1(SV1)




3-way value 2(SV2)



#### 3-way value 3(SV3)






### a) Procedure

- Connect the cable to the appropriate terminals as shown in the picture.
- Fix the cable reliably.

### 3) For zone 1 pump(P\_O)




4) For zone 2 pump(P\_M)

Connect the cable to the appropriate terminals as shown in the picture.

• Fix the cable reliably.


### 5) For zone 3 pump(P\_T)



#### a) Procedure

- Connect the cable to the appropriate terminals as shown in the picture.
- Fix the cable reliably.

### 6) For domestic hot water pump(P\_R)





### a) Procedure


- Connect the cable to the appropriate terminals as shown in the picture.
- Fix the cable reliably.

### 7) For room thermostat(Low voltage)

"POWER IN" provide the working voltage to the RT.









CN12


There are three zones for connecting the thermostat cable (as described in the picture above) and it depends on the application.

### 8) For water tank electric heating






### 10) For backup electric heating



For standard monobloc 16kW, there is no internal backup heater inside the monobloc, but the monobloc can be connected to an external backup heater, as described in the picture below.

### 11) For smart grid

The unit has smart grid function, there are two ports on PCB to connect SG signal and EVU signal as following:





1. When EVU signal is on , and SG signal is on, as long as the DHW mode is set to be valid, heat pump will operate DHW mode priority and the DHW mode setting temperature will be change to  $70^{\circ}$ C. Thwt< $69^{\circ}$ C, the TBH is on,Thwt> $70^{\circ}$ C, the TBH is off.

2. When EVU signal is on , and SG signal is off, as long as the DHW mode is set to be valid and the mode is on, heat pump will operate DHW mode priority. Thwt<Thwt(Set)-2, the TBH is on,Thwt≥Thwt(Set)+3, the TBH is off.

3. When EVU signal is off, and SG signal is on, the unit operates normally.

4. When both EVU and SG siggnal are off, the unit operates as below: The unit will not operate DHW mode, and the TBH is invalid, disinfect function is invalid. The max running time for cooling/heating is "SG RUNNING TIME", then unit will be off.





• The cascade function of the system only supports 8 machines at most.

• In order to ensure the success of automatic addressing, all machines must be connected to the same power supply and powered on uniformly.


• Only the Master unit can connect the controller, and you must put the SW3 to "on" of the master unit, the slave unit cannot connect the controller .

- Please use the shielded wire, and the shield layer must be grounded.
- Engineering load wiring must meet the requirements of double insulation and the outermost insulation thickness ≥1mm .
- · The engineering load wiring needs to be routed through pipelines or walls .


When connecting to the power supply terminal, use the circular wiring terminal with the insulation casing (see Figure 9.1). Use power cord that conforms to the specifications and connect the power cord firmly. To prevent the cord from being pulled out by external force, make sure it is fixed securely.

If circular wiring terminal with the insulation casing cannot be used, please make sure that:

• Do not connect two power cords with different diameters to the same power supply terminal (may cause overheating of wires due to loose wiring) (See Figure 9.2).



Use the same power supply, circuit breaker and leakage protectve device for the unit of cascade system



# **7 TEST RUN AND FINAL CHECKS**

The installer is obliged to verify correct operation of unit after installation.

### 7.1 Final checks

- Before switching on the unit, read following recommendations:
- · When the complete installation and all necessary settings have been carried out, close all front panels of the unit and refit the unit cover.
- The service panel of the switch box may only be opened by a licensed electrician for maintenance purposes.

#### 

During the first running period of the unit, required power input may be higher than stated on the nameplate of the unit. This phenomenon originates from the compressor that needs elapse of a 50 hours run in period before reaching smooth operation and stable power consumption.

### 7.2 Test run operation (manually)

If required, the installer can perform a manual test run operation at any time to check correct operation of air purge, heating, cooling and domestic water heating, refer to "MENU>PARAMETERS CONFIG>2.SYSTEM PARAMETERS>PASSWARD 2345>1.USER PARAMETERS SETTING>9.TEST SETTING " in wired controller.

# **8 MAINTENANCE AND SERVICE**

In order to ensure optimal availability of the unit, a number of checks and inspections on the unit and the field wiring have to be carried out at regular intervals.

This maintenance needs to be carried out by your local technician.

In order to ensure optimal availability of the unit, a number of checks and inspections on the unit and the field wiring have to be carried out at regular intervals.

This maintenance has to be carried out by your local technician.

# 

ELECTRIC SHOCK

- · Before carrying out any maintenance or repairing activity, must switch off the power supply on the supply panel.
- · Do not touch any live part for 10 minutes after the power supply is turned off.
- The crank heater of compressor may operate even in standby.
- · Please note that some sections of the electric component box are hot.
- · Forbid touching any conductive parts.
- · Forbid rinsing the unit. It may cause electric shock or fire.
- · Forbid leaving the unit unattended when service panel is removed.

The following checks must be performed at least once per year by qualified person.

Water pressure

Check the water pressure, if it is below 1 bar.fill water to the system.

- Water filter
- Clean the water filter.
- Water pressure relief valve

Check for correct operation of the pressure relief valve by turning the black knob on the valve counter-clockWise:

-If you do not hear a clacking sound, contact your local dealer.

-In case the water keeps running out of the unit, close both the water inlet and outlet shut-off valves first and then contact your local dealer.

Pressure relief valve hose

Check that the pressure relief valve hose is positioned appropriately to drain the water.

Backup heater vessel insulation cover

Check that the backup heater insulation cover is fastened tightly around the backup heater vessel.

Domestic hot water tank pressure relief valve (field supply) Applies only to installations with a domestic hot water tank. Check for correct
operation of the pressure relief valve on the domestic hot water tank.

# **9 TURN OVER TO CUSTOMER**

The owner's manual of monobloc must be turned over to the customer. Explain the contents in the owner's manual to the customers in details.

# 

- Ask your dealer for installation of the heat pump. Incomplete installation performed by yourself may result in a
- water leakage, electric shock, and fire.
  Ask your dealer for improvement, repair, and maintenance.
- Incomplete improvement, repair, and maintenance may result in a water leakage, electric shock, and fire.
- In order to avoid electric shock, fire or injury, or if you detect any abnormality such as smell of fire, turn off the power supply and call your dealer for instructions.
- Never let the monobloc or the remote controller get wet. It may cause an electric shock or a fire.
- Never press the button of the remote controller with a hard, pointed object.

The remote controller may be damaged.

• Never replace a fuse with that of wrong rated current or other wires when a fuse blows out.

Use of wire or copper wire may cause the unit to break down or cause a fire.

- It is not good for your health to expose your body to the air flow for a long time.
- Do not insert fingers, rods or other objects into the air inlet or outlet.

When the fan is rotating at high speed, it will cause injury.

• Never use a flammable spray such as hair spray,lacqueror paint near the unit.

It may cause a fire.

Never put any objects into the air inlet or outlet.

Objects touching the fan at high speed can be dangerous.

 Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact you local government for information regarding the connection systems available.

- If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the ground water and get into the food chain, damaging your health and well-being.
- · To prevent refrigerant leak, contact your dealer.

When the system is installed and runs in a small room, it is required to keep the concentration of the refrigerant, if by any chance coming out, below the limit. Otherwise, oxygen in the room may be affected, resulting in a serious accident.

The refrigerant in the heat pump is safe and normally does not leak.

If the refrigerant leaks in the room, contact with a fire of a burner, a heater or a cooker may result in a harmful gas.

 Turn off any combustible heating devices, ventilate the room, and contact the dealer where you purchased the unit.

Do not use the heat pump until a service person confirms that the portion where the refrigerant leaks is repaired.

# CAUTION -

· Do not use the heat pump for other purposes.

In order to avoid any quality deterioration, do not use the unit for cooling precision instruments, food, plants, animals or works of art.

• Before cleaning, be sure to stop the operation, turn the breaker off or pull out the supply cord.

Otherwise, an electric shock and injury may result.

• In order to avoid electric shock or fire, make sure that an earth leak detector is installed.

Be sure the heat pump is grounded.

In order to avoid electric shock, make sure that the unit is grounded and that the earth wire is not connected to gas or water pipe, lightning conductor or telephone earth wire.

- In order to avoid injury, do not remove the fan guard of the monobloc.
- Do not operate the heat pump with a wet hand. An electric shock may happen.
- Do not touch the heat exchanger fins.

These fins are sharp and could result in cutting injuries.

After a long use, check the unit stand and fitting for damage.

If damaged, the unit may fall and result in injury.

- To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the heat pump.
- Arrange the drain hose to ensure smooth drainage. Incomplete drainage may cause wetting of the building, furniture etc.
- Never touch the internal parts of the controller. Do not remove the front panel. Some parts inside are dangerous to touch, and a machine trouble may happen.
- Never do the maintenances work by yourself.
   Please contact your local dealer to do the maintenances work.
- Never expose little children, plants or animals directly to the air flow.

Adverse influence to little children, animals and plants may occur.

 Do not allow a child to mount on the monobloc or avoid placing any object on it.

Falling or tumbling may result in injury.

Do not operate the heat pump when using a room fumigation - type insecticide.

Failure to observe could cause the chemicals to become deposited in the unit, which could endanger the health of those who are hypersensitive to chemicals.

Do not place appliances which produce open fire in places exposed to the air flow from the unit .

It may cause incomplete combustion or deformation of the unit due to the heat.

• Do not install the heat pump at any place where flammable gas may leak out.

If the gas leaks out and stays around the heat pump, a fire may break out.

 The appliance is not intended for use by young children or infirm persons without supervision.

Young children should be supervised to ensure that they do not play with the appliance.

• The monobloc window-shades should be periodic cleaning in case of being jammed.

This window-shapes is heat dissipation outlet of components, if being jammed will cause the components shorten their service life spans because of overheated for a long time.

• The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.

### 10.3 Heating capacity

- The heating operation is a heat-pump process that heat will be absorbed from outdoor air and released to indoor water. Once the outdoor temperature is decreased, heating capacity decreased correspondingly.
- Other heating equipment is suggested to be used together when outdoor temperature is too low.
- In some extreme cold upland that buy the monobloc equipped with electrical heater will obtain better performance.

# 

1) The fan motor will continue running for 60 seconds for to remove residual heat when the monobloc receiving OFF command during heating operation.

2) If the heat pump malfunction occurs because of disturb, please reconnect the heat pump to power, then turn on it again.

### **10.4 Compressor protection feature**

A protection feature prevents the heat pump from being activated for approximately several minutes when it restarts immediately after operation.

### 10.5 Cooling and heating operation

The the monobloc in the same system can not run cooling and heating at the same time.

If the Heat Pump Administrator has set running mode, then the heat pump can not run on modes other than the presetted. Standby or No Priority will be displayed in the Control Panel.

### 10.6 Features of heating operation

Water will not become hot immediately at the beginning of the heating operation, 3~5 minutes ago (depends on the indoor and outdoor temperature), until the indoor heat exchanger become hot, then becomes hot.

During operation, the fan motor in the monobloc unit may stop running under high temperature.

### 10.7 Defrost in the heating operation

During heating operation, monobloc unit sometimes will frost. To increase efficiency, the unit will start defrosting automatically (about 2~10 minutes), and then water will be drained out from monobloc unit.

During defrosting, the fan motors in the monobloc will stop running.

# **10 OPERATION AND PERFORMANCE**

### **10.1 Protection Equipment**

This Protection Equipment will enable the Heat Pump to stop when the Heat Pump is to be directed running compulsively.

The protection equipment may be activated in following conditions:

#### **Cooling Operation**

- The air inlet or air outlet of monobloc is blocked.
- Strong wind is Continuously blowing to the air outlet of the monobloc unit.

### **Heating Operation**

- Too much rubbish adhere to the filter in the water system.
- The air outlet of monobloc is choked.
- · Mishandling in operation:

If mishandling happens because of lighting or mobile wireless, please shut off the manual power switch, and turn on again, then push the ON/OFF button.

# 

When the protection equipment starts, please shut down the manual power switch, and restart operation after problem is solved.

### 10.2 About power cut

If power is cut during operation, stop all the operation immediately in case of power comes again. If the auto-restart function is set on,then the unit will auto-restart.

# **11 ERROR CODES**

When a safety device is activated, an error code will be displayed on the user interface. A list of all errors and corrective actions can be found In the table below.

Reset the safety by turning the unit OFF and back ON.

In case this procedure for resetting the safety is not successful, contact your local dealer.

Err code	Malfunction or protection	The exclusion method		
d1	Abnormal outlet water temperature after auxiliary heating	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive</li> <li>The sensor failure, change a new sensor.</li> </ol>		
d2	Abnormal temperature of plate heat exchange inlet water	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. Remove the water, make the connector dry. Add waterproof adhesive.</li> <li>The sensor failure, change a new sensor.</li> </ol>		
d3	Abnormal temperature of plate heat exchange outlet water	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. Remove the water, make the connector dry. Add waterproof adhesive</li> <li>The sensor failure, change a new sensor.</li> </ol>		
d4	Plate heat exchanger refrigerant gas pipe is abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive</li> <li>The sensor failure, change a new sensor.</li> </ol>		
d5	Plate heat exchanger refrigerant liquid pipe is abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. Remove the water, make the connector dry. Add waterproof adhesive.</li> <li>The sensor failure, change a new sensor.</li> </ol>		
d6	Abnormal final outlet water temperature of the system	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor or change a new interface.</li> </ol>		
d7	Zone 1 inlet water temperature abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor or change a new interface.</li> </ol>		
d8	Zone 2 inlet water temperature abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor or change a new interface.</li> </ol>		
d9	Zone 3 inlet water temperature abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor or change a new interface.</li> </ol>		
dA	Zone 1 room temperature abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor or change a new interface.</li> </ol>		
dB	Zone 2 room temperature abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor or change a new interface.</li> </ol>		
dC	Zone 3 room temperature abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor or change a new interface.</li> </ol>		

Err code	Malfunction or protection	The exclusion method
dF	The inlet water temperature of the balance tank is abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive.</li> <li>The sensor failure, change a new sensor.</li> </ol>
dH	The outlet water temperature of the balance tank is abnormal	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive.</li> <li>The sensor failure, change a new sensor.</li> </ol>
dj	Solar Temperature Tsolar fault	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive.</li> <li>The sensor failure, change a new sensor.</li> </ol>
dn	Hot water tank temperature Thwt fault	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive.</li> <li>The sensor failure, change a new sensor.</li> <li>If you want to close the domestic water heating when sensor do not connected to the system, then sensor can not be detected.</li> </ol>
L1	The water temperature difference between plate heat exchanger inlet and outlet is too large	<ol> <li>Check that all shut off valves of the water circuit are completely open.</li> <li>Check if the water filter needs cleaning.</li> <li>Connect the water supply to the filling valves and open the valve. Filling with some water until the manometer indicates a pressure of approximately 2.0 bar.</li> <li>Make sure there is no air in the system (purge air).</li> <li>Check on the manometer that there is sufficient water pressure. The water pressure must be &gt;1 bar(water is cold).</li> <li>Check that the pump speed setting is on the highest speed.</li> <li>Make sure that the expansion vessel is not broken.</li> <li>Check that the resistance in the water circuit is not too high for the pump.</li> </ol>
L2	The water temperature difference between plate heat exchanger inlet and outlet is abnormal	<ol> <li>Check that all shut off valves of the water circuit are completely open.</li> <li>Check if the water filter needs cleaning.</li> <li>Connect the water supply to the filling valves and open the valve.Filling with some water until the manometer indicates a pressure of approximately 2.0 bar.</li> <li>Make sure there is no air in the system (purge air).</li> <li>Check on the manometer that there is sufficient water pressure. The water pressure must be &gt;1 bar(water is cold).</li> <li>Check that the pump speed setting is on the highest speed.</li> <li>Make sure that the expansion vessel is not broken.</li> <li>Check that the resistance in the water circuit is not too high for the pump.</li> </ol>
L3	Plate heat exchanger outlet water temperature is too low	<ol> <li>Check the resistance of temperature sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor.</li> <li>Check that all shut off valves of the water circuit are completely open.</li> <li>Check if the water filter needs cleaning.</li> <li>Insufficient water flow.</li> <li>Detect the amount of refrigerant.</li> </ol>
L4	Plate heat exchanger outlet water temperature is too high	<ol> <li>Check the resistance of temperature sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor.</li> <li>Check that all shut off valves of the water circuit are completely open.</li> <li>Check if the water filter needs cleaning.</li> <li>Insufficient water flow.</li> <li>Detect the amount of refrigerant.</li> </ol>
L5	Plate heat exchanger inlet water temperature is too low	<ol> <li>Check the inlet water temperature.</li> <li>Check the resistance of temperature sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor failure, change a new sensor.</li> </ol>
L6	Plate heat exchanger inlet water temperature is too high	<ol> <li>Check the inlet water temperature</li> <li>Check the resistance of temperature sensor</li> <li>The sensor connector is loosen. Reconnect it</li> <li>The sensor failure, change a new sensor.</li> </ol>
L7	Water side antifreeze	<ol> <li>Check the resistance of the two sensor .</li> <li>Check the two sensors locations .</li> <li>The water sensor is loosen. Reconnect it.</li> <li>The water sensor is broken, change a new sensor.</li> <li>Four-way valve is blocked. Restart the unit again to let the valve change the direction.</li> <li>Four-way valve is broken, change a new valve.</li> </ol>

Err code	Malfunction or protection	The exclusion method
L8	Insufficient water flow fault	<ol> <li>Check whether the water flow switch is installed loosely.</li> <li>Check that all shut off valves of the water circuit are completely open.</li> <li>Check if the water filter needs cleaning.</li> <li>Connect the water supply to the filling valves and open the valve. Filling with some water until the manometer indicates a pressure of approximately 2.0 bar.</li> <li>Make sure there is no air in the system (purge air).</li> <li>Check on the manometer that there is sufficient water pressure. The water pressure must be &gt;1 bar(water is cold).</li> <li>Check that the pump speed setting is on the highest speed.</li> <li>Make sure that the expansion vessel is not broken.</li> <li>Check that the resistance in the water circuit is not too high for the pump.</li> <li>If this error occurs at defrost operation (during space heating or domestic water heating), make sure that the backup heater power supply is wired correctly and that fuses are not blown.</li> <li>Check that the pump fuse and PCB fuse are not blown.</li> </ol>
Lb	Auxiliary electric heating feedback failure	<ol> <li>Interface wiring disconnected.</li> <li>There is no water in the water tank when the auxiliary electric heating is started.</li> <li>Check whether the temperature Controller is reset, it can be reset manually.</li> </ol>
LC	Water tank electric heating feedback failure	<ol> <li>Interface wiring disconnected.</li> <li>There is no water in the water tank when the electric heating is started.</li> </ol>
Ld	Emergency frequent defrosting	1. Detect the amount of refrigerant.
LE	External water pump failure	<ol> <li>Poor connection of water pump wiring.</li> <li>The water pump is failure, change a new water pump.</li> </ol>
LP	Main water pump fault	<ol> <li>Poor connection of water pump wiring.</li> <li>The water pump is failure, change a new water pump.</li> </ol>
C1	Multiple master control failure	<ol> <li>When an internal machine is connected with two line controllers, if both line controllers are set as main line controllers, report to C1.</li> <li>Solution: One wire controller is set as the master and the other wire controller is set as the slave.</li> </ol>
C7	WiFi communication failure	Replace the wire controller.
E0	Communication failure between indoor unit and outdoor unit	<ol> <li>Check whether the communication wire is properly connected and in good contact.</li> <li>Whether there is a high magnetic field or high power interfere, such as lifts, large power transformers, etc To add a barrier to protect the unit or to move the unit to the other place.</li> </ol>
E3	The temperature sensor in the middle of the plate heat exchanger is faulty	<ol> <li>Check the temperature of the coolant tube.</li> <li>Check the resistance of the temperature sensor.</li> <li>The sensor connector is loose. Reconnect.</li> <li>If the sensor is faulty, replace it with a new one.</li> </ol>
E4	System maintenance data abnormal	<ol> <li>Check the system maintenance function Settings.</li> <li>Check the system maintenance data.</li> </ol>
E5	DIP abnormal	<ol> <li>Check whether the dip switch of the model is normal.</li> <li>Check whether the cascaded models are consistent.</li> </ol>
E7	Outdoor temperature sensor failure	Check whether the temperature sensor is normal.
E8	Exhaust temperature sensor failure	Check whether the temperature sensor is normal.
EA	Outdoor current sensor failure	<ol> <li>Check cables to the monobloc current sensor.</li> <li>Replace the current sensor.</li> <li>Replace the outdoor control panel.</li> </ol>
Eb	Communication failure between indoor unit and wire controller	<ol> <li>Check whether there is any abnormality in the connecting line between the line controller and the electric control board, and replace the connecting line.</li> <li>If the wire controller is abnormal, replace it.</li> <li>If the electric control board is abnormal, replace it.</li> </ol>

Err code	Malfunction or protection	The exclusion method
EC	Communication failure between drive board and main PCB	<ol> <li>Check whether the power supply of the monobloc is correct.</li> <li>Check whether the communication line between monobloc is connected correctly.</li> </ol>
Ed	Indoor unit EE error	1.Initialize all parameters. 2.main control board of monobloc is broken, change a new PCB.
EE	Outdoor EEPROM failure	1.Initialize all parameters. 2.main control board of monobloc is broken, change a new PCB.
EF	Outdoor DC fan failure	<ol> <li>Strong wind or typhoon below toward to the fan, to make thefan running in the opposite direction. Change the unit direction or make shelter to avoid typhoon below to the fan.</li> <li>Check whether the PWM fan wiring is normal</li> <li>Fan motor is broken, change a new fan motor.</li> </ol>
Ej	Communication failure between indoor unit and thermostat	<ol> <li>Check the communication line between the internal machine and the temperature controller.</li> <li>Change the thermostat.</li> <li>Replace the inner machine plate.</li> </ol>
EH	Malfunction of outdoor air intake sensor	Check whether the communication wire is properly connected and in good contact.
En	Module communication error	1.Check the wiring method of cascade function. 2.Check the dialing code of cascade address.
F2	Outdoor exhaust temperature sensor failure protection	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. remove the water, make make the connector dry.add waterproof adhesive.</li> <li>The sensor failure, change a new sensor.</li> </ol>
F3	Outdoor coil temperature sensor failure protection	Check whether the temperature sensor is normal.
F5	PFC protection	<ol> <li>Check fan, air duct and ambient temperature.</li> <li>Extend acceleration time.</li> <li>Check compressor model and model parameters.</li> <li>Check the input voltage.</li> <li>Please power off for a few minutes, then power on again and start again.</li> <li>Check whether the PFC inductor lead wire or inductor coil is. short-circuited, or seek service.</li> <li>Check mechanical system, compressor refrigerant, etc., or seek service.</li> </ol>
F6	Compressor loss/reverse phase protection	<ol> <li>Check the installation wiring.</li> <li>Check the input voltage.</li> <li>Adjust parameters to eliminate oscillation.</li> </ol>
F7	Module temperature protection	Power off and then power on and try again, if the problem still exists, please seek service.
F8	4 way valve reversing failure (heating mode)	<ol> <li>Whether the wiring of the four-way valve is correct;</li> <li>Whether the power supply voltage of the monobloc is too low, resulting in abnormal reversing of the 4-way valve.</li> <li>If the fault still cannot be solved, consult the manufacturer.</li> </ol>
FA	Compressor phase current detection failure	Power off and then power on and try again, if the problem still exists, please seek service.
Fy	lack of refrigerant	Check whether the unit leaks refrigerant. If there is leakage, the leak point needs to be repaired.

Err code	Malfunction or protection	The exclusion method
H1	High pressor switch protection	<ul> <li>Check whether compressor high pressure switch is normal.</li> <li>Heating mode, DHW mode: <ol> <li>The water flow is low; water temp is high, whether there is air in the water system. Release the air.</li> <li>Water pressure is lower than 0.1Mpa, charge the water to let the pressure in the range of 0.15~0.2Mpa.</li> <li>Over charge the refrigerant volume. Recharge the refrigerant in right volume.</li> <li>Electrical expansion valve locked or winding connector is loosen.</li> <li>Tap-tap the valve body and plug in/ plug off the connector for several times to make sure the valve is working correctly. And install the winding in the right location DHW mode: Water tank heat exchanger is smaller .</li> <li>Cooling mode:</li> <li>The finned heat exchanger cover is not removed. Remove it.</li> <li>The finned heat exchanger or remove the obstruction.</li> </ol> </li> </ul>
H2	Low pressor switch protection	<ol> <li>Check whether compressor low pressure switch is normal.</li> <li>Lack of refrigerant. Charge the refrigerant in right volume.</li> <li>When at heating mode or DHW mode, the finned heat exchanger is dirty or something is block on the surface. Clean the finned heat exchanger or remove the obstruction.</li> <li>The water flow is too low in cooling mode.increase the water flow.</li> <li>Electrical expansion valve locked or winding connector is loosen.</li> <li>Tap-tap the valve body and plug in/ plug off the connector for several times to make sure the valve is working correctly.</li> </ol>
H3	High pressure sensor failure	<ol> <li>Check whether the sensor is connected properly.</li> <li>Pressure sensor failure, change a new sensor.</li> </ol>
P0	IPM module protection, compressor overcurrent, IPM overcurrent, inverter module protection	1. The IPM module is damaged. 2. The IPM module and heat sink are improperly installed.
P1	DC bus overvoltage, undervoltage, voltage overvoltage, undervoltage, AC input undervoltage	<ol> <li>Check input power supply,wiring.</li> <li>Check input voltage.</li> <li>Check and replace.</li> </ol>
P2	AC input overcurrent	<ol> <li>Check whether the working load of the unit is out of range.</li> <li>Check whether there are foreign bodies in the inlet and outlet of the external machine.</li> <li>Check whether the system is blocked.</li> </ol>
P4	Exhaust temperature too high protection	<ol> <li>Check the resistance of the sensor.</li> <li>The sensor connector is loosen. Reconnect it.</li> <li>The sensor connector is wet or there is water in. remove the water, make the connector dry. Add waterproof adhesive.</li> <li>The sensor failure, change a new sensor.</li> <li>Check for lack of refrigerant.</li> </ol>
P5	Refrigeration anti-overcooling failure	Whether the water flow is sufficient during heating, and whether the Y-shaped filter is dirty and blocked, resulting in insufficient water flow.
P6	Refrigeration prevents overheating failure	Check whether the fin heat exchanger of the monobloc dissipates heat well during cooling, and whether the condenser is dirty or blocked.
P7	Heating protection against overheating	Whether the water flow is sufficient during heating, and whether the Y-shaped filter is dirty and blocked, resulting in insufficient water flow.
P8	Outdoor ambient temperature too high and too low protection	Ambient temperature is too low or too high.

# **12 TECHNICAL SPECIFICATIONS**

Unit model	8kW	8kW(3kW heater)	10kW	10kW(3kW heater)		
Power supply	220-240V 1N~50Hz					
Rated power input	3300W	3300W+3000W	3600W	3600W+3000W		
Rated current	15.5A	28.5A	17A	30A		
Norminal capacity		Refer to the	technical data			
Dimensions (W×H×D)[mm]		1293×8	360×495			
Packing (W×H×D)[mm]		1395×9	996×535			
Fan motor		DC motor	/ Horizontal			
Compressor		DC inverte	r dual rotary			
Heat exchanger		Fin	-coil			
Refrigerant						
Туре		R	32			
Quantity		14	00g			
Water side heat exchanger		Plate heat	exchanger			
Electric heater	-	3kW	-	3kW		
Rated water pressure		0.	3MPa			
Filter mesh			80			
Min. water flow (flow switch)		13 L	./min			
Pump						
Туре		DC	inverter			
Max. head	9m					
Power input	5~90W					
Expanssion vessel						
Volume	8L					
Max. operating pressure	0.3MPa(g)					
Pre-charge pressure	0.1MPa(g)					

Weight							
Net weight	90.5kg	95kg	90.5kg	95kg			
Gross weight	111.5kg	116kg	111.5kg	116kg			
Connections							
Water inlet/outlet			R5/4"				
Operation ambient temperat	ure range						
Cooling mode		-{	5 ~ 43°C				
Heating mode	-25 ~ 35°C						
Domestic hot water mode	-25 ~ 43°C						
Water outlet temperature rai	nge						
Outlet water(cooling model)		5	5 ~ 20°C				
Outlet water(heating model)	25 ~ 65°C						
Domestic hot water	20 ~ 60°C						
Water pressure	0.1 ~ 0.3MPa						
The temperature range of wi	red controller using						
Storage temperature	-10 ~ 60°C						
Operating temperature		-10	) ~ 50°C				
	1						

Unit model	12kW	12kW(3kW heater)	14kW	14kW(3kW heater)	16kW	16kW(3kW heater)
Power supply	220-240V 1N~50Hz					
Rated power input	5400W	5400W+3000W	5800W	5800W+3000W	6200W	6200W+3000W
Rated current	25.5A	38.5A	27.5A	40.5A	29.5A	42.5A
Norminal capacity			Refer to the	e technical data		
Dimensions (W×H×D)[mm]			1293;	<860×495		
Packing (W×H×D)[mm]			1395	<996×535		
Fan motor			DC moto	r / Horizontal		
Compressor			DC invert	er dual rotary		
Heat exchanger			F	in-coil		
Refrigerant						
Туре				R32		
Quantity				1740g		
Water side heat exchanger			Plate he	at exchanger		
Electric heater	-	3kW	-	3kW	-	3kW
Rated water pressure				0.3MPa		
Filter mesh				80		
Min. water flow (flow switch)			13	L/min		
Pump						
Туре			DC	Cinverter		
Max. head	9m					
Power input	5~90W					
Expanssion vessel						
Volume	8L					
Max. operating pressure	0.3MPa(g)					
Pre-charge pressure			0.	1MPa(g)		

Weight						
Net weight	107.5kg	112kg	107.5kg	112kg	107.5kg	112kg
Gross weight	128.5kg	133kg	128.5kg	133kg	128.5kg	133kg
Connections						
Water inlet/outlet				R5/4"		
Operation ambient temperatu	ire range					
Cooling mode			-5	~ 43°C		
Heating mode	-25 ~ 35°C					
Domestic hot water mode			-25	5 ~ 43°C		
Water outlet temperature range	ge					
Outlet water(cooling model)			5	~ 20°C		
Outlet water(heating model)	25 ~ 65°C					
Domestic hot water	20 ~ 60°C					
Water pressure	0.1 ~ 0.3MPa					
The temperature range of wir	ed controller usi	ng				
Storage temperature	-10 ~ 60°C					
Operating temperature			-10	~ 50°C		

Unit model	12kW	12kW(6kW heater)	14kW	14kW(6kW heater)	16kW	16kW(6kW heater)
Power supply	380-415V 3N~50Hz					
Rated power input	5400W	5400W+6000W	5800W	5800W+6000W	6200W	6200W+6000W
Rated current	9.0A	18.0A	9.5A	18.5A	10.0A	19.0A
Norminal capacity		1	Refer to the	e technical data		1
Dimensions (W×H×D)[mm]			1293>	<860×495		
Packing (W×H×D)[mm]			1395>	<996×535		
Fan motor			DC moto	r / Horizontal		
Compressor			DC invert	er dual rotary		
Heat exchanger			Fi	n-coil		
Refrigerant						
Туре				R32		
Quantity			1	740g		
Water side heat exchanger			Plate he	at exchanger		
Electric heater	-	6kW	-	6kW	-	6kW
Rated water pressure			(	).3MPa		1
Filter mesh				80		
Min. water flow (flow switch)			13	L/min		
Pump						
Туре			DC	C inverter		
Max. head	9m					
Power input	5~90W					
Expanssion vessel						
Volume	8L					
Max. operating pressure	0.3MPa(g)					
Pre-charge pressure				1MPa(g)		

Weight						
Net weight	119.5kg	124kg	119.5kg	124kg	119.5kg	124kg
Gross weight	140.5kg	145kg	140.5kg	145kg	140.5kg	145kg
Connections						
Water inlet/outlet			I	R5/4"		
Operation ambient temperatu	re range					
Cooling mode			-5	~ 43°C		
Heating mode			-25	5~ 35°C		
Domestic hot water mode			-25	5~43°C		
Water outlet temperature rang	ge					
Outlet water(cooling model)			5	~ 20°C		
Outlet water(heating model)	25 ~ 65°C					
Domestic hot water	20 ~ 60°C					
Water pressure	0.1 ~ 0.3MPa					
The temperature range of wire	ed controller usi	ng				
Storage temperature	-10 ~ 60°C					
Operating temperature			-10	~ 50°C		

Unit model	12kW(9kW heater) 14kW(9kW heater) 16kW(9kW heater)						
Power supply	318-415V 3N~50Hz						
Rated power input	5400W+9000W	5800W+9000W	6200W+9000W				
Rated current	22.0A	22.5A	23.0A				
Norminal capacity		Refer to the technical data					
Dimensions (W×H×D)[mm]		1293×860×495					
Packing (W×H×D)[mm]		1395×996×535					
Fan motor		DC motor / Horizontal					
Compressor		DC inverter dual rotary					
Heat exchanger		Fin-coil					
Refrigerant							
Туре	R32						
Quantity		1740g					
Water side heat exchanger		Plate heat exchanger					
Electric heater		9kW					
Rated water pressure		0.3MPa					
Filter mesh		80					
Min. water flow (flow switch)		13 L/min					
Pump							
Туре		DC inverter					
Max. head		9m					
Power input	5~90W						
Expanssion vessel							
Volume	8L						
Max. operating pressure	0.3MPa(g)						
Pre-charge pressure	0.1MPa(g)						

Weight	
Net weight	124kg
Gross weight	145kg
Connections	
Water inlet/outlet	R5/4"
Operation ambient temperature range	
Cooling mode	-5 ~ 43°C
Heating mode	-25 ~ 35°C
Domestic hot water mode	-25 ~ 43°C
Water outlet temperature range	
Outlet water(cooling model)	5 ~ 20°C
Outlet water(heating model)	25 ~ 65°C
Domestic hot water	20 ~ 60°C
Water pressure	0.1 ~ 0.3MPa
The temperature range of wired controller using	
Storage temperature	-10 ~ 60°C
Operating temperature	-10 ~ 50°C

#### 1) Checks to the area

Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.

#### 2) Work procedure

Works shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.

#### 3) General work area

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out, work in confined sapces shall be avoided. The area around the work space shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.

#### 4) Checking for presence of refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. no sparking, adequately sealed or intrinsically safe.

#### 5) Presence of fire extinguisher

If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry power or  $CO_2$  fire extinguisher adjacent to the charging area.

#### 6) No ignition sources

No person carrying out work in relation to a refrigeration system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. NO SMOKING signs shall be displayed.

#### 7) Ventilated area

Ensure that the area is in the open or that it's adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

#### 8) Checks to the HVAC equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using flammable refrigerants:

- The charge size is in accordance with the room size within which the refrigerant containing parts are installed;
- · The ventilation machinery and outlets are operating adequately and are not obstructed;

• If an indirect refrigerating circuit is being used, the secondary circuits shall be checked for the presence of refrigerant; marking to the equipment continues to be visible and legible.

• Marking and signs that are illegible shall be corrected;

• Refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are • suitably protected against being so corroded.

#### 9) Checks to electrical devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, and adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

Initial safety checks shall include:

- · That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- That there no live electrical components and wiring are exposed while charging, recovering or purging the system;
- · That there is continuity of earth bonding.

#### 10) Repairs to sealed components

a) During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

b) Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

· Ensure that apparatus is mounted securely.

• Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacture's specifications.

The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Instrinsically safe components do not have to be isolated prior to working on them.

#### 11) Repair to intrinsically safe components

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use. Intrinscially safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating. Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.

#### 12) Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

#### 13) Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

#### 14) Leak detection methods

The following leak detection methods are deemed acceptable for systems containing flammable refrigerants. Electronic leak detectors shall be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration.(Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25% maximum) is confirmed. Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work. If a leak is suspected, all naked flames shall be removed or extinguished. If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated(by means of shut off valves) in a part of the system remote from the leak. Oxygen free nitrogen(OFN) shall then be purged through the system both before and during the brazing process.

#### 15) Removal and evacuation

When breaking into the refrigerant circuit to make repairs of for any other purpose conventional procedures shall be used. However, it is important that best practice is followed since flammability is a consideration. The following procedure shall be adhered to:

- Remove refrigerant;
- · Purge the circuit with inert gas;
- Evacuate;
- · Purge again with inert gas;

Open the circuit by cutting or brazing.

The refrigerant charge shall be recovered into the correct recovery cylinders. The system shall be flushed with OFN to render the unit safe. This process may need to be repeated several times.

#### Compressed air or oxygen shall not be used for this task.

Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant in the system.

When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. This operation is absolutely vital if brazing operations on the pipe-work are to take place. Ensure that the outlet for the vacuum pump is not closed to any ignition sources and there is ventilation available.

#### 16) Charging procedures

In addition to conventional charging procedures, the following requirements shall be followed:

Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.

- Cylinders shall be kept upright.
- · Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
- Label the system when charging is complete(if not already).
- Extreme care shall be taken not to overfill the refrigeration system.
- Prior to recharging the system it shall be pressure tested with OFN. The system shall be leak tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

#### 17) Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken.

In case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

#### a) Become familiar with the equipment and its operation.

b) Isolate system electrically.

c) Before attempting the procedure ensure that:

• Mechanical handling equipment is available, if required, for handling refrigerant cylinders;

• All personal protective equipment is available and being used correctly;

- The recovery process is supervised at all times by a competent person;
- · Recovery equipment and cylinders conform to the appropriate standards.

d) Pump down refrigerant system, if possible.

e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.

f) Make sure that cylinder is situated on the scales before recovery takes place.

g) Start the recovery machine and operate in accordance with manufacturer s instructions.

h) Do not overfill cylinders. (No more than 80% volume liquid charge).

i) Do not exceed the maximum working pressure of the cylinder, even temporarily.

j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.

k) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

#### 18) Labeling

Equipment shall be labeled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

#### 19) Recovery

When removing refrigerant from a system, either for service or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct numbers of cylinders for holding the total system charge are available. All cylinders to be used are designated for the recovered refrigerant and labeled for that refrigerant(i.e special cylinders for the recovery of refrigerant). Cylinders shall be completed with pressure relief valve and associated shut-off valves in good working order.

Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs. The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order.

Hoses shall be completed with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste

Transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

20) Transportation, marking and storage for units.

Transport of equipment containing flammable refrigerants Compliance with the transport regulations.

Marking of equipment using signs Compliance with local regulations.

Disposal of equipment using flammable refrigerants Compliance with national regulations.

Storage of equipment/appliances.

The storage of equipment should be in accordance with the manufacturer's instructions.

Storage of packed (unsold) equipment.

Storage package protection should be constructed such that mechanical damage to the equipment inside the package will not cause a leak of the refrigerant charge.

The maximum number of pieces of equipment permitted to be stored together will be determined by local regulations.